8 (800) 222-03-94 8 (495) 532-03-23

Приём звонков: Пн-Пт с 9:00 до 18:00



https://vbg-cosmetic.ru/





**User Manual** 

# Contents

Product detail	1
Basic operation	3
Intelligent hand-piece	5
Needles head installation	6
Adjustment of needles depth	6
Needles head introduction	7
Specification	8
Precaution	9



- 1 Speed up
- ③ Speed down
- 6 Power switch
- 7 Power interface

- Start/Pause button
  - Function keys
- 6) Pedal
- (8) Hand piece interface





PMU marks the color pigments inhale into the needle by injecting them to skin by a back-and-forth motion

MTS helps medical supplies be absorbed to skin by irritating

### Basic Operation

1.Place accessories well and connect to main body



Cord of adapter connect to power interface (Operating like fig 1 and fig 2)



Fig 3 Fig 4
Cord of hand piece connect to hand piece interface
(Operating like fig 3 and fig 4)



Fig 5 Fig 6
Cord of pedal connect to pedal interface
(Operating like fig 5 and fig 6)

- 2.Plug DC charger to AC outlet
- 3.Click ( to turn on the machine and it shows like Fig 7



Fig 7

- Choose the mode on the menu. The icon will flash after clicking the function key.
- 5.Click to select the speed level
- 11 speed levels. Higher level, higher speed
- Click to start or pause the hand-piece.
   Or use pedal to control the hand-piece.

### Stationary mode



The pen will stop working automatically when it stays on the placement area.

#### Operating mode



The pen will start working automatically when it leaves the placement area.

- Take out needles cartridges from the sterilized package.
- 2. Pushing the needle cartridge horizontally into the round slot of pen.
- Assemble the needles cartridges by clockwise rotation take apart the needles cartridges by counterclockwise rotation.
- 4.Adjustment of needle length should be done after turning on the machine.




## Adjustment of needles depth

Adjusting the depth of needle by turning the needles depth adjustment.

- -Turn it clockwise, needle depth will be longer.
- -Turn it counterclockwise, needle depth will be shorter





## Specification

[Model name]: ARTMEX-V9

【Weight】: 2100g

[Adapter]: 100V~240V

[Size]:290mm\*273mm\*105mm

[Patented product]: Yes

[Purpose of Use]: Permanent make-up & Micro-needle Therapy

### Maintenance

#### 1.General maintenance

- -Keep it with power off. Wipe its surface up with a dry cloth.
- -Keep it away from direct sunlight or high temperature and humidity.
- Do not leave the measurement, repair or alter of the device to non-professional staff.

#### 2. Routine inspection

- -Make sure to inspect the device and adapter before use.
- -When you use the device which has not been used for a long time, make sure to check if it works properly with safety.

## Package list

Host	1 pc		
Hand piece	1 pc		
Adapter	1 pc		
Pedal	1 pc		



$\sim$	Alternating current	SN	Serial No	
	Direct current	EC REP	EU Representative	
	Class II equipment	Œ	CE mark	
A	Attention, consult accompanying documents		Manufacturer	
M	Date of manufacture	F	Floating applied part	
0	Please be sure to read instructions before use and follow as described.			
<u>^</u>	Do not apply it to the man as follow:  1.Who has acute disease or bloody disease over 38°C  2.Who has allergy and hemophilia  3.Who has melanosis of the face  4.Who has high internal heat  5.Who regularly visits hospital  6.Who takes medicines  7.Who is under 12 years old			
0	Do not use it on the power other than AC 220V. It may cause fires or mailfunction			
0	Do not use it near the place with high temperature, dust or humidity (Near the humidifier).It may cause malfunction.			
0	Do not repair, disassemble or after the controller and the body. It may cause malfunction.			
0	Do not touch the device or detach the power cords with wet hands. It may cause electric shock.			
0	Do not use the stripped cord or propped cord. It may cause fires(Be sure to replace it with another).			
0	Do not use the propped cord which has crack or scares. It may cause scares on the skin.			
0	When you don't use it for a long time, unplug it from the outlet.			
0	Be sure to have an inspection for test. If any troubles are found, get it repaired.			
0	No one other than the operator can touch it. It may cause accidents or malfunction.			